

Instructions
Air Pump Test Gauge Item #RO284

This gauge was developed to determine air pump performance. It is dynamic in operation, simulating correct flow rate @ 3 psi.

Step 1

- 1) Turn off ozone generator.
- 2) Remove cover.

Step 2

Connect test gauge as illustrated.

Step 3

- 1) Hold test gauge vertical.
- 2) Turn on ozone generator.

Step 4

If ball is centered at green line or above, air pump performance is to specification.
One ball below green line, less than acceptable.
Two balls below green line, air pump is need of replacement or rebuilding.

