



## **Installation Instructions**

### **Plastic Lamp Assembly Item #PLA-100**

Congratulations on your purchase. If you have any questions please call.

**Note: Always disconnect power before servicing.**

#### **Step 1**

- 1) Turn off ozone generator.
- 2) Remove cover.

#### **Step 2**

- 1) Unplug old lamp from ballast.
- 2) Pull off 1/8 inch air pump tubing (norprene) from old lamp.
- 3) At right hand side of old lamp, cut tubing in half, remove tubing and clamp attached to cabinet bulkhead.
- 4) Remove old lamp.

#### **Step 3**

- 1) Install new lamp.
- 2) Connect lamp plug to ballast plug.
- 3) Cut 1/2 inch from air pump tubing and install onto new lamp.
- 4) Install new output tubing and clamps provided.
- 5) Use pliers to tighten clamps, two to three clicks pass snug.
- 6) Turn on ozone generator.

#### **Note #1:**

Do not use zip ties on 1/8 inch ID norprene tubing used to connect air pump outlets and plastic lamp assembly inlets. Fresh cut tubing is sufficient, zips ties can actually cause leakage if used on 1/8 inch ID norprene tubing.

#### **Note #2:**

Please use zip ties on all 3/16 inch ID vinyl/norprene tubing connections. This tubing is used from the exit of ozone generator (vinyl) to top of tank and inside tank (norprene).

Email: [customerservice@revolutionozone.com](mailto:customerservice@revolutionozone.com)

RevolutionOzone.com - P.O. Box 370, Philo, CA 95466 - Phone: 707 397 5069

Revolution Ozone is a K. Wells Manufacturing Company

All Contents and Images Copyright © 2013-2018

**Layout Instructions**

**Note: Always disconnect power before servicing.**

This illustration depicts location of components

